




# seliger®

Version: 01/2021

State of print: 12/2021



## PRODUCT INFORMATION

Designation:	seliger connect  single
Article-No.:	920001
Range of application:	Control via Bluetooth
Overall performance:	1,2 W
Maximum performance:	150 W
IP-Class:	IP44
Input voltage:	24V DC
Controllable lamps:	Sky Pro Micro, Mini, Spot, Max, Mega warm white

## APPLICATION

The connect single models can be controlled via the Seliger smart app.

The model connect single can only be used and controlled in conjunction with the app. The use of the connect multi is described below:

1. Connect the connect single to the power supply unit.
2. Plug the power supply unit into the socket.
  - The pilot lamp on the connect single connect component lights up green.

In its basic setting, the lamp lights up permanently white with 100% brightness.

### Downloading the app

The Seliger smart app can be downloaded via the website [www.seliger.eu](http://www.seliger.eu) or via the QR code specified in chapter 6.2.

Proceed as follows to use the Seliger smart app in conjunction with the connect single:

1. Activate Bluetooth on your mobile phone and share your location.
2. Start the Seliger smart app.
  - Agree to the data protection ordinance.



3. Please create an account if you are downloading the Seliger smart app for the first time. Please log in if you already have an account.



## Registrieren

Deutschland



max@mustermann.de



Verifizierungscode abrufen



## Geben Sie den Bestätigungscode ein

8 1 8 9 5 \_

Der Bestätigungscode wurde Ihnen per E-Mail gesendet.  
[max@mustermann.de](#) erneut senden(23s)

Hast du keinen Code bekommen?

1	2	3	⌫
4	5	6	OK
7	8	9	.-
	0		/

00:00


4. Enter your e-mail address. You will receive a confirmation code via e-mail.
5. Enter the confirmation code within 60 seconds.


You can now use the Seliger smart app.

## Establishing a connection:



1. Press the button on the connect component for 3 seconds.
  - The pilot lamp blinks for 3 minutes, the white lamp also blinks for 3 minutes
2. Establish the connection via the Seliger smart app.
  - If no connection has been established with the device after 3 minutes, please press the button on the connect component again.

## Integrating the connect single into the Seliger smart app



1. Open the Seliger smart app and click on the pushbutton  in the top right corner.
  - The connect single is recognised automatically.

2. Please follow the instructions on the screen to add the connect single.
- If the connect single is not recognised after 10 seconds, follow step 3.





Gescannte 1 Geräte, 1 Geräte wurden  
erfolgreich hinzugefügt




connect single




WEITER

3. After you have pressed the pushbutton , select the pushbutton "Automatic scan".







4. Click on Continue.

5. Wait until the connection has been established. As an option, you can assign the connect single its own name via the ✎ symbol, then click on Continue.



6. In the overview, click on Complete to finish integrating the connect single.
- As soon as the connect single has been successfully added, you will find it on the start page.

If the connection has not been successful, reset the device and try again.

## Resetting the device:

1. If the connect single had already been connected, remove it from the app.
2. Hold the reset button on the connect component depressed for 5 seconds.



To view the different functions and description of the Seliger smart app, please go to:

[www.seliger.eu/Help](http://www.seliger.eu/Help)

---

Seliger GmbH  
Kuthmühleweg 6  
78050 Villingen  
Germany  
[info@seliger.eu](mailto:info@seliger.eu)  
[www.seliger.eu](http://www.seliger.eu)

